



## BESTWARE Hardware Production Co., Ltd.

Add: Block 8, No.6, Jianda Nan Road, Jiangmen, Guangdong, China

Website: [www.bestware-stainless.com](http://www.bestware-stainless.com)

Email: [business@bestware-stainless.com](mailto:business@bestware-stainless.com)    [after-sales@bestware-stainless.com](mailto:after-sales@bestware-stainless.com)

WhatsApp: +86 18929047065    Tel: +86 750 3108801

Wechat: +86 18929047065



Website



YouTube



WhatsApp



Wechat

2026 V1.0



## Manual Drinking Bubbler User and Installation Manual



BUBL-PB




BUBL-CH




BUBL-LH

PREMIER SOLUTION PROVIDER OF ONE-STOP STAINLESS COMMERCIAL FAUCETS


### 1.Function Overview



**BUBL-PB**




**BUBL-CH**




**BUBL-LH**


### 2.Operating Instructions



Press the Handle for Water Flow




Twist the Handle for Water Flow



Swing the Handle for Water Flow  
(360-degree Swing to Release Water)

**3. Adjust the Water Flow Rate: Use a flathead screwdriver to loosen the valve cap, then turn the adjustment rod while the faucet is running.**



#### 4. Operating Instructions (Wall Mount)

- ① After making the mounting hole in the wall, insert the screw plug into the hole. Wrap the PTFE tape around the wall-mounted threaded pipe, then connect the faucet to the pipe. Use the wrench to tighten the connection, and then use the screwdriver to tighten the screws.

