



BESTWARE Hardware Production Co., Ltd.

Add: Block 8, No.6, Jianda Nan Road, Jiangmen, Guangdong, China

Website: www.bestware-stainless.com

Email: business@bestware-stainless.com after-sales@bestware-stainless.com

WhatsApp: +86 18929047065 Tel: +86 750 3108801

Wechat: +86 18929047065



Website



YouTube



WhatsApp



Wechat

2026 V1.0




Sushi Faucet User and Installation Manual



SSLT

PREMIER SOLUTION PROVIDER OF ONE-STOP STAINLESS COMMERCIAL FAUCETS


1.Function Overview




SSLT

2.Operating Instructions

- ❶ Press and turn the handle to start water flow. Release to automatically return and stop the water.



- ❷ The spout swivels 360°.




3.Tools Required




4.Installation Procedure

- 1 Faucet Installation: Drill the mounting hole and insert the faucet into the hole. Install the mounting nut and tighten the phillips screw.



- 2 Inlet Hose Installation: Use the inlet hose to connect the faucet to the angle valve, then tighten the connections with a wrench.



- 3 Tube Check: Open the angle valve, then check whether the tubing leaks and whether it functions properly.

